

## Service Information no. 199

### Typhoon Oil Free Compressor

---

We have noted that our oil free compressor, due to heat, stops running after only 12 min./hour. It turns out that the pressure level of the overpressure valve is too high (8.8 bar).

This can be solved by changing the overpressure valve to a 5.5 bar valve. Using this valve will make the compressor able to run for approx. 15-25 min./hour.

If you experience this problem, please order item no: 110 001 187, and we will forward the new overpressure valve to you f.o.c.



**Item no: 110 001 187**

Should you need any further information do not hesitate to contact Nilfisk-ALTO Food Division sales department, direct tel. No.: +45 7218 2000.

Best regards  
**Nilfisk-ALTO Food Division**

Niels Chr. Thygesen  
Dir. tf.: +45 7218 2006 - [Niels.christian.thygesen@nilfisk-alto.com](mailto:Niels.christian.thygesen@nilfisk-alto.com)